AAS-PROVIDED PDF • OPEN ACCESS

Robust Support for Semi-automated Reductions of Keck/NIRSPEC Data Using Pypelt

To cite this article: Adolfo S. Carvalho et al 2024 Res. Notes AAS 8 271

Manuscript version: AAS-Provided PDF

This AAS-Provided PDF is © 2024 The Author(s). Published by the American Astronomical Society.



Original content from this work may be used under the terms of the Creative Commons Attribution 4.0 licence. Any further distribution of this work must maintain attribution to the author(s) and the title of the work, journal citation and DOI.

Everyone is permitted to use all or part of the original content in this article, provided that they adhere to all the terms of the licence https://creativecommons.org/licences/by/4.0

Before using any content from this article, please refer to the Version of Record on IOPscience once published for full citation and copyright details, as permissions may be required.

View the article online for updates and enhancements.

DRAFT VERSION OCTOBER 25, 2024 Typeset using LATEX twocolumn style in AASTeX631

Robust support for semi-automated reductions of Keck/NIRSPEC data using PypeIt

Adolfo S. Carvalho,¹ Greg Doppmann,² Kyle B. Westfall ^(D),³ Debora Pelliccia,³ J. Xavier Prochaska,⁴ Joseph Hennawi,^{5,6} Frederick B. Davies,⁷ Max Brodheim ^(D),⁸ Feige Wang,^{9,10} and Ryan Cooke ^{(D)11}

¹Department of Astronomy; California Institute of Technology; Pasadena, CA 91125, USA

²W. M. Keck Observatory, 65-1120 Mamalahoa Hwy, Kamuela, HI, USA

³University of California Observatories, University of California, Santa Cruz, 1156 High St., Santa Cruz, CA 95064, USA

⁴University of California, Santa Cruz; 1156 High St., Santa Cruz, CA 95064, USA

⁵Physics Department, Broida Hall, University of California, Santa Barbara, CA 93106-9530, USA

⁶Leiden Observatory, Leiden University, PO Box 9513, 2300 RA Leiden, The Netherlands

⁷Max-Planck-Institut für Astronomie, Königstuhl 17, D-69117 Heidelberg, Germany

⁸W. M. Keck Observatory, Waimea, HI 96743, USA

⁹Department of Astronomy, University of Michigan, 1085 S. University Ave., Ann Arbor, MI 48109, USA

¹⁰Steward Observatory, University of Arizona, 933 N Cherry Avenue, Tucson, AZ 85721, USA

¹¹Centre for Extragalactic Astronomy, Durham University, Durham, DH1 3LE, UK

ABSTRACT

We present a data reduction pipeline (DRP) for Keck/NIRSPEC built as an addition to the PypeIt Python package. The DRP is capable of reducing multi-order echelle data taken both before and after the detector upgrade in 2018. As part of developing the pipeline, we implemented major improvements to the capabilities of the PypeIt package, including manual wavelength calibration for multi-order data and new output product that returns a coadded spectrum order-by-order. We also provide a procedure for correcting telluric absorption in NIRSPEC data by using the spectra of telluric standard stars taken near the time of the science spectra. At high resolutions, this is often more accurate than modeling-based approaches.

1. INTRODUCTION

The high resolution Near InfraRed SPECtrograph (NIR-SPEC, McLean et al. 1998) on the W. M. Keck Observatory delivers a resolving power $R \equiv \lambda/\Delta\lambda = 15,000 - 35,000$ from 0.95 to 5.5 μ m. Prior to 2018, there were three recommended software options for reducing NIRSPEC data: the IDL package REDSPEC¹, the IRAF package WMKON-SPEC², and the semi-automated Python pipeline NSDRP³. In 2018, the instrument underwent a major detector upgrade, in which the 1024x1024 detector was replaced by a 2048x2048 detector. Post-upgrade, only REDSPEC was updated to reduce the data from the new detector, rendering NSDRP and WMKONSPEC usable only for pre-upgrade data.

In order to enable NIRSPEC users to rapidly reduce new and archival data, we used the existing data reduction pipeline package PypeIt (Prochaska et al. 2020). PypeIt is a python-based data-reduction package that enables automated processing of raw on-sky observations and calibration data from slit-based spectrographs. Separate workflows are im-

¹ https://www2.keck.hawaii.edu/inst/nirspec/redspec.html

plemented for long-slit, multi-slit, slicer-based integral-field units, and cross-dispersed echelle observations; however, all workflows leverage the same core code to perform common tasks. Instrument-specific code is isolated from the core code in a way that limits the development needed to introduce new spectrographs into the PypeIt architecture. Although *enabling* PypeIt to read and apply its routines to data from additional spectrographs is streamlined, ensuring that the PypeIt reductions are *reliable and robust* requires dedicated development effort.

In this Note, we detail this effort for PypeIt reductions of Keck/NIRSPEC data, applicable to data obtained both before and after the detector upgrade in 2018. The pipeline includes improvements to the main PypeIt code and a procedure for the removal of telluric absorption in NIRSPEC spectra using telluric standard star spectra. The pipeline is available at the PypeIt Github page (https://github.com/pypeit/PypeIt) and an example script outlining the telluric removal procedure is provided in the Keck/NIRSPEC instrument webpage and linked in Section 3.

2. UPDATES TO PYPEIT

Developing the PypeIt-NIRSPEC module required two major upgrades to the PypeIt main data reduction code. The first, and most impactful, was the expansion of the PypeIt

² https://www2.keck.hawaii.edu/inst/nirspec/wmkonspec.html

³ https://www2.keck.hawaii.edu/koa/nsdrp/nsdrp.html

manual wavelength calibration program to operate on echelle data. The second was the construction of a new data structure as a default output for PypeIt reductions of echelle data. Here, we will briefly describe the two upgrades.

The original user-interface-based manual wavelength calibration in PypeIt was written for calibrating only a single trace, which is appropriate in the case of long-slit spectroscopy or for multi-object spectroscopy where each trace is expected to have approximately the same wavelength solution. To wavelength calibrate the multi-trace echelle spectra, the script now iterates through each extracted order, prompts the user to compute a solution for the order through a userinterface, then saves the solution and proceeds to the next order. Upon completing all of the orders, the multi-trace solution is saved so that it may be used for any data set taken with the same grating settings. The script was tested with data and calibrations taken at different times with independent instrument configurations. It can handle spectral shifts and spatial shifts (8 and 25 pix, respectively) typical of the variation in the positioning accuracy of NIRSPEC's gratings.

The second major update to PypeIt was in the output products. Previously, the final co-added output spectrum, even for high resolution echelle spectrographs, was presented in a single masked vector spanning the entire wavelength range of the spectrum. While this is ideal for low and medium resolution spectroscopy, particularly when the spectra are properly flux-calibrated, this can make working with high resolution spectra challenging. Now, for high resolution echelle spectra, a second output product is offered: the co-added spectrum given as an $N \times M$ array for the N orders of the spectrum and M columns on the detector. This is an output format that is standard in other data reduction pipelines for high resolution spectra, including NSDRP.

3. TELLURIC CONTAMINATION CORRECTION

The recommended telluric correction technique for NIR-SPEC data is to use standard A0V star spectra taken throughout the night at varying airmasses to ensure accurate removal of atmospheric absorption features. To then remove the telluric features from the observed spectrum requires the following steps:

- 1. Continuum normalizing the standard star and science target spectra.
- 2. Fitting and dividing out the stellar photospheric features of the (ideally A0V) standard.
- 3. Shifting the newly-obtained telluric absorption spectrum to match the science target in case of instrumental wavelength shifts between observations.
- 4. Uniform scaling the line depths of the telluric absorption spectrum to account for differences in airmass between observations.
- 5. Dividing the shifted and scaled telluric absorption spectrum from the science target spectrum.

We make use of several tools in the PypeIt package for this procedure, particularly the cross-correlation-based approach used to compute the relative shifts between spectra. A well-documented notebook showing how to extract the output PypeIt data and implement the steps above is provided at https://www2.keck.hawaii.edu/inst/nirspec/pypeit_nirspec. html to guide the user. We recommend this as a means of telluric correction, which is based on the popularly-used telluric correction program in IRAF. An example showcasing the efficacy of our telluric correction is shown in Figure 1.

In the Y and J bands, observations taken using the thin blocker filter are also subject to severe fringing that is worse in bluer orders. The fringing is stable as a function of wavelength over the course of the night and appears in both the standard and science spectra at the same amplitude relative to continuum. As such, using a standard star for telluric correction in the same night as the observed science target enables easy removal of the fringing as well. This is demonstrated in the case of the J band spectrum presented in Figure 1.

If standard star observations are not available for a particular night or a desired spectrograph setup, PypeIt offers a modeling-based means of telluric line removal. However, the model-based removal is less reliable at the highest resolutions and performs poorly in Y and J band spectra that have significant fringing.

4. ACKNOWLEDGEMENTS

Software: Astropy (Astropy Collaboration et al. 2013, 2018, 2022), NumPy (Harris et al. 2020)

REFERENCES

- Astropy Collaboration, Robitaille, T. P., Tollerud, E. J., et al. 2013, A&A, 558, A33, doi: 10.1051/0004-6361/201322068
- Astropy Collaboration, Price-Whelan, A. M., Sipőcz, B. M., et al. 2018, AJ, 156, 123, doi: 10.3847/1538-3881/aabc4f
- Astropy Collaboration, Price-Whelan, A. M., Lim, P. L., et al. 2022, ApJ, 935, 167, doi: 10.3847/1538-4357/ac7c74
- Harris, C. R., Millman, K. J., van der Walt, S. J., et al. 2020, Nature, 585, 357, doi: 10.1038/s41586-020-2649-2





Figure 1. Upper Left: A sample quality assurance plot from the wavelength calibration of Order 60 in the J band. **Upper Right:** Order 60 of the A0V telluric standard spectrum (black) and the PHOENIX model (red) used to remove the Pa β line to produce a telluric absorption spectrum. **Bottom Panel:** A plot of Order 65 of the science spectrum (black), the telluric spectrum (green) and the telluric-corrected spectrum (red). Notice that the fringing is also removed by the division by the telluric absorption spectrum.

- McLean, I. S., Becklin, E. E., Bendiksen, O., et al. 1998, in Society of Photo-Optical Instrumentation Engineers (SPIE) Conference Series, Vol. 3354, Infrared Astronomical Instrumentation, ed. A. M. Fowler, 566–578, doi: 10.1117/12.317283
- Prochaska, J., Hennawi, J., Westfall, K., et al. 2020, The Journal of Open Source Software, 5, 2308, doi: 10.21105/joss.02308